



Pocket ACTRATM



FEATURES

Works with EPAC and 2070ATC controllers

Upload and download controller data

Monitor status of Intersections

Key in or display SE-PAC data from the 2070ATC (3C) controller front panel

Initialize modems, set baud rates

Windows CE Operating System


Reference manuals available using Microsoft Pocket Word™

TRAFFIC DATA MANAGEMENT





Transfer data from one EPAC or 2070ATC to another



Set up remote communications



Monitor vehicle phases, ped phases, and point in cycle counters



View data using the 2070ATC (3C) front panel emulation